JTS PROFESSIONAL CO., LTD.

850CH-2 / G3CH-2

2/8-Slot Charger

850CH-2 / CH-8 CHARGER For
RU-850LTH & RU-850LTB & R-4THA & R-4TB

G3CH-2 / CH-8 CHARGER For
RU-G3TH & RU-G3TB & R-4TBM & UF-20TB



JTS® PROFESSIONAL CO., LTD.
No. 148, 9th Industry Road, Ta-Li Industrial Park,
Taichung City, Taiwan.
Tel: 886-4-24938803 Fax: 886-4-24914890
E-mail: jts@jts.com.tw
www.jts.com.tw

Made in Taiwan

59516-101-05

1. Parts Identification

850CH-2



G3CH-2



Adaptor (100-240V input, 1A for CH-2 3.3A for CH-8 12V output)

Rechargeable battery
(4 rechargeable battery
included with CH-2 /
16 rechargeable battery
included with CH-8)



CH-2
(2-Slot Charger)



CH-8
(8-Slot Charger)

2. Specification

CH-2 (2-Slot Charger) / CH-8 (8-Slot Charger)
Input: AC 100~240V, 0.4A max(CH-2)
AC 100~240V, 1.2A max(CH-8)
Output: DC 12V, 1A(CH-2)
DC 15V, 3A(CH-8)

LED Indicator
Full Charged / Standby: Green
Charging: Flash Green
Fault: Red light flashes 1 time : Battery overheated
Red light flashes 2 times : Battery voltage too high
Red light flashes 4 times : Battery short circuit
Red light flashes 8 times : Battery voltage too low

Charging Time: 5 hours
(2000mAh rechargeable battery)

3. Charge Battery

Plug the RU-G3TH / RU-G3TB / RU-850LTH / RU-850LTB / R-4THA / R-4TB / R-4TBM / UF-20TB into "Charger Slot" CH-2 or CH-8.
The charging indicator will flash green light when it is charging, and the green light will stop flashing when it is fully charged.

Noted 1: As soon as AC power is connected, the charging indicator will show green light.
Noted 2: Please follow the direction and **push the transmitters to the end till it touch the charging point** as show in below demonstration picture.
Noted 3: One charger Slot can only charge one item at a time.





Noted 2

850CH-2 / G3CH-2

2/8-Slot Charger

850CH-2 / CH-8 CHARGER For RU-850LTH & RU-850LTB
G3CH-2 / CH-8 CHARGER For RU-G3TH & RU-G3TB